
ON ADAPTING NEW 8.25 × 16.5 RIMS

Earl Mayer 2750 N. 95 Milwaukee, Wis. 53222



WHICH MAY INTERFERE WITH CLOSE FITTING NEW RIMS

SPARE TIRE CARRIER

PRISTING STUDS
NOT USED

V2 WOOD
SPACERS

NEW RIM

DRILL 2
9/6 HOLES
IN CARRIER
6/2
APART

2- 9/16 x 3 HARDENED BOLTS HOLD RIM TO CARRIER WITH WASHERS AND NUTS. WHOLE ASSEMBLY FASTENED TO COACH WITH EXISTING STUD AND LUG NUT. SPACER RING ON COACH MAY HAVE TO BE CUT TO CLEAR NEW BOLT HEAD.