


CHRYSLER SLANT SIX CHOKE STOVE SUBSTITUTION

10

When your choke stove burns out and a replacement is not available, here is a simple remedy.

The area for the original choke used on the manifold for cars is an ideal place to run the choke stove line.

Cut a paper pattern that will cover the area on the top and back side, picking up the two attach holes for $\frac{1}{4}$ x $\frac{1}{2}$ long bolts and lock washers. Transfer the pattern to a piece of sheet stock and cut and bend. Drill two holes to match the holes in the manifold and a hole between $\frac{1}{4}$ diameter. Punch the center hole to enlarge it so it can be tapped to $\frac{1}{8}$ pipe. By using a punch it will flange inward and have sufficient material to tap. Install a 90 degree fitting in the cover and attach to the manifold. Form a copper $\frac{1}{4}$ line from the choke to the new stove. Cover with an asbestos or fiberglass sleeve. Install with nuts and ferrels to choke and new stove.



Joel C. Smith
21582 Polynesian Lane
Huntington Beach, Ca. 92646